

Connect the datalogger to the corresponding 4-pin COM port of the inverter. A Solis 5K inverter is used here as an example.

Please follow the instructions below:



WiFi Stick Datalogger **Quick Installation Manual**

Version: 3.1



Delivery Content ■1 WiFi stick

1 WiFi Antenna

■1 Quick Installation Manual

Install the datalogger





Match the joint

1. Install the antenna to the datalogger



Only rotate the black circle, not the sliver cover.

1. The device must be installed away from the strong magnetic field produced by large electrical appliances such as microwave oven, refrigerator, telephone, metal walls, etc. Otherwise, the communication quality may be affected. It may also be affected by lighting storm.

- 2. The [RESET] button on the back is used for connection.
- ·Short press will send the data immediately. Long press for 5 seconds will reset the connection.
- The three constantly ON LED lights indicate the datalogger is working normally.

Install the datalogger:

- 2. Insert the datalogger to the inverter COM port
- 3. Rotate the black circle clockwise





∠ WiFi Configuration

Step 1: Use you phone to scan the QR code to download and register the Solis Cloud APP. Or directly download from APP Store or Google Play Store by searching "SolisCloud".



Step 2: If it is a new datalogger, please configure it first, then click the "WiFi configre".

Welcome to ginlong

Log in

Hello

LED Lights Status:

cators	Description	Status	Meanings	
ternet icators (NET)	Shows the connection status between the datalogger and the server.	Flashing	Trying to connect with server	
		ON	Successfully connected	
		OFF	Abnormal connection	
ter COM icators COM)	Shows the connection status between datalogger and the inverter.	Flashing	Trying to connect with inverter	
		ON	Successfully connected	
		OFF	Abnormal connection	
ower licator PWR)	Shows the power supply status of the datalogger.	ON	Datalogger is powered up normally	S th
			Dataloggeris	

ors	Description	LED Status	Meanings	
et ors T)	Shows the connection status between the datalogger and the server.	Flashing	Trying to connect with server	
		ON	Successfully connected	
		OFF	Abnormal connection	
COM ors M)	Shows the connection status between datalogger and the inverter.	Flashing	Trying to connect with inverter	
		ON	Successfully connected	
		OFF	Abnormal connection	
er tor	Shows the power supply	ON	Datalogger is powered up normally	Ste the


abnormally

Step 3: Manually fill in the datalogger SN or Scan



Step 4: Click "o,", make sure the phone is connected

to router WiFi and switch back to the page to fill in the WiFi password, then move to next step.



until the yellow and green LEDs are quickly flashing.

Start to configure

Please open the configuration mode of the

Long press for 5 Yellow and green lights seconds flash simultaneously

collector

Step 5: Long press the "Reset" button for 5 seconds



Please click "WiFi configure"

e SN on the datalogger.



Step 6: Wait for around 10 seconds. After the configuration completed, click "OK" and back to the main page. If failed, re-do the configuration process or contact the after-sale engineers.

Configuration succeeded


Datalogger SN:5011981679800A7C

Router-WLAN



4 Create Plant Create the Soliscloud Account

Step1: Select Owner or Installer for email address registration. the "Add plant" at the bottom.



Step2: Enter your account and password, then click



Step1: Enter the main page of Soliscloud APP, click



Step 2: Input the information of the plant as required. Then click "Done".



Step 3: Confirm the plant information. Click "Create a plant".




homepage, then add the datalogger.



Cancel

manually input it.



Note: Scan the datalogger SN, NOT the inverter SN.

100 m

Can't find barcode?

Scan Album



Step 5: Scan the SN number of the datalogger or Step 6: Plant creation succeeds.Click "Continu...atalogger" to check the monitoring data. If

> the plant has multiple dataloggers, please click "View Plant".



Please contact us if you have any technical problems in terms of the product. Please provide the following information as well:

- ◆Inverter SN
- ◆ Datalogger SN
- ◆ Problem Description

Ginlong Technologies Co., Ltd.

No. 57 Jintong Road, Binhai Industrial Park, Xiangshan, Ningbo, Zhejiang, 315712, P.R.China.

Tel: +86 (0)574 6578 1806 Fax: +86 (0)574 6578 1606 Email: info@ginlong.com Web: www.ginlong.com